How To Attach The Strap To The Middle Of The Blanket.

Cb'U'\_]XbYmcf']ffY[i`Uf'g\UdYX'dcc`ž'h\Y'fYY`k cf\_g'VYghk \Yb']h`]g'Z]hHYX'UWcgg'h\Y'dcc` Uh'h\Y'k ]XYgh'dUfh'Ug'g\ck b']b'Diagram 2"'H\]g'U`ck g'h\Y'V'Ub\_Yh'nc'fc``ZfYY`mcbhc'h\Y' fYY`UbX'a U\_Yg']ha i W YUg]Yf hc fc``cb UbX cZZh\Y dcc`"

There are two methods to use to fasten the straps to the pool cover. The "double layer" method is where you fold the cover aligned with the tube and fasten through 2 layers to create a stiffer edge to assist the blanket to fold and roll more easily. The "single layer" method is where you fasten the straps through the cover with the screw coming from the under side and the clip and strap on top directly underneath the tube.

K ]h\`h\Y``Xci V`Y``UnYf<sup>\*\*</sup>a Yh\cXž'h\Y`ghfUdg`UfY`ZUghYbYX`hc`U`) \$a a `Zc`XYX`gYVhjcb`cZ'h\Y` V`Ub\_Yh'X]fYVhimi bXYfbYUh\`h\Y`U`i a ]b]i a `hi VY`i gjb[`h\Y`d`Ugh]WgMfYk g'`=XYU`Zcf`bYk Vkj Yfg`VYZcfY`h\YmUfY`hf]a a YX`hc`gjnY`Ug`nci `bYYX`Ub`YI hfU`%\$\$a a `]b``Yb[h\`Zcf`h\]g a Yh\cX`hc`k cf\_`VYgh'`9UWk ghfUd is fastened Yj Yb`mgdUWYX`UMfcgg'h\Y`hi VYž'h\fci [\`hk c` `UnYfgcZh\YV`Ub\_YhUgg\ckb]b Diagram 8.

H\Y`'g]b[`Y``UnYf'''a Yh\cX`]g'hc`ZUghYb'h\Y`V`Ub\_Yh'W]d'hc'h\Y'hcd`cZ'h\Y`Wej Yf`X]fYWfim i bXYfbYUh\`h\Y`U`i a ]b]i a `h`VY''`H\Y`gWfYk`]g'di g\YX`h\fci [\`Zfca`h\Y`Wej Yf`g]XY`k]h\`h\Y 'W]d'UbX`ghfUd`cb`hcd`cZ'h\Y`Vej Yf''`H\]g]g'U`[ccX`a Yh\cX`Zcf`YI]gh]b[`V`Ub\_Yhg`cf`Vej Yfg` h\Uh\Uj Y`U`fYUXmVYYb'Whhc`h\Y`g\UdY`cZ'h\Y`dcc``Ug`]h'fYei]fYg'bc`YI hfU`ZUVf]\W`*Refer* Diagram 9.

Adjust the length of the ghfUdg'Uh'Y]h\Yf'YbX'i g]b[`h\Y'Vi W\_Y'fDiagram 10½'cf'V'Ub\_Yh'W]d' fDiagram 9½''AU\_Y'g fY'h\Y'`Yb[h\'cZ'h\Y'ghfUdg'UfY'Yj YbUbX'WgffYWd''J ariations in the length of the dfud will effect how straight the blanket rolls up, so it is important to adjust the length carefully. If you test roll the blanket onto the tube and it rolls unevenly, unroll it, adjust the length of the drfUds and roll it again until the Vlanket rolls evenly.

Fitting Your Overcover.

The reel kit has been supplied with a protective cover to use when the blanket has been rolled onto the tube. You will j c]X h Y k UffUbhmof most pool Vlankets if you do not cover it when stored on a reel.

Follow the separate instructions for fitting the overcover. Be sure to cover the blanket every time it is rolled onto the tube hc dfch/Vh/jh/Zfca '\YUh/Vi ]'X'i d'h\UhcWV/fgk \Yb' fc``YX'i d'UbX'YI dcqYX'hc'h\Y'q b.

Mci 'UfY'bck 'fYUXmhc'a U\_Y'i g]b[ 'nci f'ZcUh]b[ 'dcc` Wcj Yf'ei ]W\_'UbX'YUgmigc'nci 'Wb' Yb/cmh\Y'a Ul]a i a 'VYbYZlhg'cZ'\Uj]b[ 'nci f'dcc' Wdj YfYX'k \Yb']h']g'bch']b'i gY.

#### Warranty

Your 9bXi fUbW Feel Gystem is warranted for a full 12 months, and pro rata for up to ZI Y years on the components against faulty workmanship. If you find a component is faulty, post it pre-paid to: Hydrotools P/L, DC 6cl % \*\* 6fck bg DUlbg 67, Qld 41% with a copy of your proof of purchase UbX nci f dcdhU UXXfYqq. A replacement dUfh will be posted VUW to you.

#### Frequently asked questions

- The tube has a small dent in it, will this Uffect the performance of the reel? Provided the tube remains straight, the performance will not be Uffected by a dent or mark on the tube.
- How can I move the reel when the blanket is stored on it? Your 9bXi fUbW reel system can be outfitted with heavy-duty castors (optional) and can then be easily rolled about.
- Where do I position the reel when I have to fold a section of my blanket? Position the reel at the opposite end to any section of the blanket that needs to be folded when stored on the reel. The fold creates an extra thickness on one side that will cause the blanket to roll unevenly and therefore this should be kept to a minimum.









Diagram %\$







# For Inground Solar Pool Covers Installation Instructions



Hydrotools Pty. Ltd. ACN 107 829 603 ABN 45 107 829 603

) \* AU bYgi a '8fi Y, Crestmead, Queensland 4132 Australia

www.hydrotools.com.au Email: sales@hydrotools.com.au

## INSTALLATION INSTRUCTIONS

Thank you for purchasing a Hydrotools Pool Roller (reel). Please follow the instructions carefully to protect your warranty and enjoy years of hassle-free use.

Please use your pool blanket and reel in the manner it was intended for:

- Your pool blanket is not a safety cover
- Remove the pool blanket and reel assembly from the pool completely before swimming.
- Do not store the pool blanket on the ground in direct sunlight, as it will shorten the life of the blanket and may damage your lawn.
- Always cover your pool blanket with U'dfchYVM j Y overcover, when it is stored on the reel

### Preparation And Assembly

Check that you have all the items and assemble as illustrated belowz gca Y hya ga UmVY g dd YX b h Y Vcl h Uh WebhU]bgh\YhiVY:



#### Positioning The Pool Roller

For rectangular pools, place Reel at either end of the pool. : cf']ffY[i`Uf'q\UdYX'dcc`qz'd`UWY'FYY`Uh' k]XYqhidc]bhicZih\Yidcc`" Mti ik]`` bYYXihciZJqhYbih\Y V<sup>\*</sup>Ub\_Yhac<sup>\*</sup>]hi bk ]bXq ]b Hk c X]fYVM[cbd" FYZYf \* 8]U[ fUa & UbX 8]U[ fUa g, / - cb bYI hdU[ Y"

#### Fitting The Blanket

Follow the instructions supplied with your pool blanket and fit it to the pool before you attach the blanket to the tube. The blanket will be easier to remove from not f pool if it has been trimmed to the exact size of the pool. Small gaps at the edges do not affect the function of the pool blanket. Some pool blankets are trimmed larger than the size of the pool to prevent leaves and debris from entering the water. These can still be used with a storage reel, but can be a little more difficult to operate due to the extra drag caused by the excess material cb h Y gXYg when handling.

Assembling The Tube Set

- "hi VYqUfY`qYWfY`UbX`Xc`bch`q`]XY`cf`a cj Y"

# ...U][bYX'\c`YqZfca `cbY`d]XY'hc`h\Y`ch\Yf`UbX'h\Yb`h][\Hyb`h\Y'bi h"



We recommend that your pool reel be a minimum of 300 mm wider than your pool blanket. See diagram 2 for information on positioning, so it rolls on more easily.

#### Attaching The Straps

7\YW.h\Y.dpfUdgUfY.Yj.Yb`madUWX.UWicagh\Y.Wej.Yf": UdhYb.h\Y.dpfUd.Vmd]YfWbj.h\Y.V.Ub\_Yh.k.]h\.U.dc]bhYX.dWirk: Xf]j Yf cf a Yhu hjd dYb" H\Yb di g\ h\Y d UqhjWqd][ch h\fci [\ h\Y dcc Wej Yf UbX qbUd h\Y hk c q]XYg hc[Yh\Yf" 5X'i ghih\Y``Yb[h\`cZ'h\Y`ghfUd`i g]b[`h\Y`Vi W\_Y'dfcj]XYX`Uh'Y]h\Yf`YbX"`=h]gimportant`h\Y``Yb[h\`cZ'h\Y`ghfUdg[]jY` Yj Yb`hYbg]cb`k \Yb`fc``]b[`i d`h\Y`dcc``V¢jYf"CbWY`U``h\Y`ghfUdg`\UjY`VYYb`UX'i ghYX`]b``Yb[h\žfc```h\Y`V¢jYf`cbhc h\Y`FYY``UbX`W(YW\_h\Y`WejYf`]gfc``]b[`YjYb`m' Z]hfc``ghc`cbY`g]XYž`]ha YUbgh\Y`ghfUdgUfY`bchYjYb`gc`nci bYYX` hc i bfc``'h\Y'Vej Yf'UbX'UX'i gh'h\Y''Yb[h\ cZ'h\Y'ghfUdgUbX'hYgh'fc``']hi d'U[U]b"'8c'h\]gi bh]`'h\Y'Vej Yf'fc``gb]W' UbX Yi Yb m' H\]qUX'i qha Ybh hc [Yh]h f][ \hk ]``a U\_Y ]h YUqYf Zcf nci Yi Yfmhla Y nci 'i qY h\Y Vei Yf"



1. @ccdY`mUddYa V`Y`hi VYg'hc[Yh\Yf`UbX'dosition where the reel will operate. AU Y`qi fY`hi VYg'UfY'' \$\$a a 'k ]XYf h\Ub'dcc`" 2. Slide any excess width into adjoining tubes, dividing it up as equally aspossible. Note: You must have a minimum of 450 mm overlap in each tube for stability. =bgYfhghfUdg]bhc h VY \_Ynk UmUbX gdUW Yj Yb mUfci bX \*\$\$a a 'UdUfh'' 3. Using the & hi VY``cW]b[`d]bog`]bqYfh]bhc`\_Ynk Umcb`]bbYf`hi VY`Zfca`YUW\`YbX`i bh]``^i qh'h\Y`qWYk`\YUX`]qj]]q]V`Y" Nti ····aUmbYYX1cc`]Zhih\Y1ciHYfihiVY1c1U`ck\_Ybci[\1[Ud1Zcfih\Y1`cW]b[id]b1c1q]XY1bqXY1\Y1ciHYfihiVY"'H][\HYb1qc1h\Y

("5`][b`h\Y`V`UV\_d`d`Uqh]W]bqYfh`\c`Yqk ]h\ h\Y`&`Vc`h`\c`YqUhYUW(YbX`UbX`di q\ Z|fa`m]bq]XY`h\Y`U`i a ]b]i a `]bbYf`h VY''

) "G]XY h\Y WUb\_`\UbX`Y`]bg]XY h\Y VYUf]b[`UbX`h\fci [\`h\Y`k \YY`" H\Yb`U`][b`k ]h\`h\Y`\c`Yg`]b`h\Y`h`VY`]bgYfh'UbX`di g\ ːŹļfa`mibh]`U``h\Y`\c`Yg`]bY`id`fU`ia]b]ia`hiVYžd`Ugh]W]bgYfh'UbX`W/Ub\_`\UbX`Y`g\UZhŁDih'U`a YhU`Vc`h'h\fci[\`h\Y`